

## SHOT EXTRA MINI CENTER Ø 158 mm

13W ELECTRÓNICO




| COLOR  | K    | CLAVE     |
|--------|------|-----------|
| BLANCO | 2700 | L1916-110 |
| BLANCO | 4100 | L1916-1F0 |
| BLANCO | 6500 | L1916-1G0 |
| NEGRO  | 4100 | L1916-3F0 |




## SHOT EXTRA MINI CENTER NÍQUEL SATÍN Ø 158 mm

13W ELECTRÓNICO STEEL




| COLOR        | K    | CLAVE     |
|--------------|------|-----------|
| NÍQUEL SATÍN | 2700 | L1917-B10 |
| NÍQUEL SATÍN | 4100 | L1917-BF0 |
| NÍQUEL SATÍN | 6500 | L1917-BG0 |



## SHOT EXTRA MINI CENTER BRASS Ø 158 mm

13W ELECTRÓNICO STEEL




| COLOR | K    | CLAVE     |
|-------|------|-----------|
| BRASS | 2700 | L1917-D10 |
| BRASS | 4100 | L1917-DF0 |
| BRASS | 6500 | L1917-DG0 |



## SHOT EXTRA MINI CENTER CROMO Ø 158 mm

13W ELECTRÓNICO STEEL



| COLOR | K    | CLAVE     |
|-------|------|-----------|
| CROMO | 4100 | L1917-CF0 |
| CROMO | 6500 | L1917-CG0 |

